


Fire Series and Ghost Rider Wiring

Earth Fire, Storm Fire, Mountain Fire, Ghost Rider

Wiring for Fire Series and Ghost Rider humbucker pickup using one toggle or push pull switch (on-on)



The switch outputs are from the middle terminals.

In the up position, the top terminals will be connected to the middle terminals.

In the down position, the bottom terminals will be connected to the middle terminals.

The Red lead is the full live and should be connected opposite the green (full earth)

The White lead is the tapped live and should be connected opposite the black (tapped earth)

The Cyan switch output is connected to earth.
The Magenta switch output is connected to live.

Each pickup requires a separate switch.